

SIM800 Series_FM_Application Note_V1.00





Document Title	SIM800 Series_FM_Application Note	
Version	1.00	
Date	2013-10-18	
Status	Release	
Document Control ID	SIM800 Series_FM_ Application Note_V1.00	

General Notes

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of Shanghai SIMCom Wireless Solutions Ltd, copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2013



Contents

1.	\mathbf{FM}	Introduction	5
	1.1.	Features	5
2.	AT (Commands	6
	2.1.	AT+FMOPEN Open FM	6
	2.2.	AT+FMCLOSE Close FM	7
	2.3.	AT+FMFREQ Set FM Frequency	7
	2.4.	AT+FMVOLUME Set FM Volume	7
	2.5.	AT+FMSCAN Auto Search Channel	8
	2.6.	AT+FMSIGNAL Query Signal Level	8
3.		mples	
Ap	pendi	ix	10
	A R	Related Documents	10
		Terms and Abbreviations	



Version History

Date	Version	What is new	Author
2013-10-18	1.00	New version	Yong.lu

Scope

This document presents the AT commands of FM operation and application examples. This document can apply to SIM800 series modules, including SIM800L and SIM800H.



1. FM Introduction

This chapter introduces the FM application features of SIM800 series modules.

1.1. Features

FM is frequency modulation radio. The frequency range is limited from 875 to 1080 (87.5MHZ-108.0MHZ). It supports auto search channel.

NOTE: If there is an incoming call after FM function is on, FM will be shut off automatically when incoming call is finished, FM will not re-open automatically.



2. AT Commands

SIM800 series FM AT command overview.

Command	Description
AT+FMOPEN	Open FM
AT+FMCLOSE	Close FM
AT+FMFREQ	Set FM Frequency
AT+FMVOLUME	Set FM Volume
AT+FMSCAN	Auto Search Channel
AT+FMSIGNAL	Query Signal Level

2.1. AT+FMOPEN Open FM

AT+FMOPEN Op	oen FM		
Test Command	Response		
AT+FMOPEN=?	+FMOPEN: (0-1)		
	ОК		
	Parameter		
	See Write Command		
Read Command	Response		
AT+FMOPEN?	+FMOPEN: <status>,<device></device></status>		
	OK		
	Parameter		
	See Write Command		
	If the status is 0,the default device is 0,but the device is meaningless.		
Write Command	Response		
AT+FMOPEN=<	OK		
device>	ERROR		
	Parameter		
	<status> 0 FM is closed</status>		
	1 FM is opened		
	<device> 0 Main audio channel</device>		
	1 Aux audio channel		
Reference	Note		



2.2. AT+FMCLOSE Close FM

AT+FMCLOSE	Close FM
Execution	Response
Command	OK
AT+FMCLOSE	ERROR
Reference	Note

2.3. AT+FMFREQ Set FM Frequency

AT+FMFREQ Set FM Frequency			
Test Command	Response		
AT+FMFREQ=?	+FMFREQ: (875-1080)		
	OK		
	Parameter		
	See Write Command		
Read Command	Response		
AT+FMFREQ?	+FMFREQ: <freq></freq>		
	OK		
	Parameter		
	See Write Command		
Write Command	Response		
AT+FMFREQ=<	OK		
freq>	ERROR		
	Parameter		
	<freq> 875-1080 The FM frequency. The range is limited from 875 to</freq>		
	1080 (87.5 MHz - 108.0 MHz)		
Reference	Note		
	FM must have been opened.		

2.4. AT+FMVOLUME Set FM Volume

AT+FMVOLUME Set FM Volume		
Test Command	Response	
AT+FMVOLUM	+FMVOLUME: (0-6)	
E=?		
	OK	
	Parameter	
	See Write Command	
Read Command	Response	
AT+FMVOLUM	+FMVOLUME: <value></value>	



E?		
	Parameter	
	See Write Command	
Write Command	Response	
AT+FMVOLUM	OK	
E= <value></value>	ERROR	
	Parameter	
	<value> <u>0</u>-6 volume level</value>	

2.5. AT+FMSCAN Auto Search Channel

AT+FMSCAN Auto Search Channel		
Execution	Response	
Command	[<channel></channel>	
AT+FMSCAN	[<cr><lf> < channel >]]</lf></cr>	
	OK	
	Parameter	
	<channel> auto search channel</channel>	
Reference	Note	
	FM must have been opened.	

2.6. AT+FMSIGNAL Query Signal Level

AT+FMSIGNAL	Query Signal Level	
Write Command	Response	
AT+FMSIGNAL	+FMSIGNAL: freq[<freq>]:<level></level></freq>	
= <freq></freq>		
	OK	
	Parameter	
	<freq> 875-1080 The FM frequency. The range is limited from 875 to</freq>	
	1080 (87.5 MHz - 108.0 MHz)	
	<le>elevel> 0-112 Signal Level</le>	
Reference	Note	
	FM must have been opened.	



3. Examples

In the "Grammar" columns of following tables, input of AT commands are in black , module return values are in blue.

Grammar	Description
AT+FMOPEN=1	Open FM. FM data would be outputted
OK	through aux audio channel
AT+FMVOLUME=6	Set FM volume
OK	
AT+FMSCAN	Auto search FM channel
948	
950	
952	
932	
954	
956	
962	
0.60	
968	
OK	
AT+FMFREQ=948	Set FM channel at 94.8MHZ
OK	200 2 212 0.11111101 UU / 11021 22 22
AT+FMSIGNAL=948	Query 94.8MHZ signal level
+FMSIGNAL: freq[948]:32	
OK	
AT+FMCLOSE	Close FM
OK	



Appendix

A Related Documents

SN	Document name	Remark
[1]	SIM800 Series_AT Command Manual	

B Terms and Abbreviations

Abbreviation	Description
FM	Frequency Modulation Radio



Contact us:

Shanghai SIMCom Wireless Solutions Co.,Ltd.

Address: Building A, SIM Technology Building, No. 633, Jinzhong Road, Shanghai,

P. R. China 200335 Tel: +86 21 3252 3300 Fax: +86 21 3252 3020 URL: www.sim.com/wm